




Tenningslås

Varenummer: EE 35630-U



- 1. Strøm inn + 30
- 2. Gløding +19
- 3. Start +50



- 0. Av
- 1. Start
- 2. Gløding
- 3. Start