



Tenningslås

Varenummer: FG 1871583



- 1. Strøm inn +30
- 2. Radio +15/54
- 3. Gløding +19
- 4. Tenning +15
- 5. Start +50

